
Mounting Accessories


REGULATOR MOUNTING BRACKETS

Regulators and integral filter/regulators can be mounted to a surface with a bracket that attaches to the regulator. Brackets and mounting nuts can be ordered separately or in a kit which includes both bracket and mounting nut.



SENTRY and MINIATURE

Kit: A33-82, Bracket: 33-82, Nut: 10R-26



GUARDSMAN and GUARDSMAN II


Kit: K60R-15, Bracket: 60R-15, Nut: 60R-14P

R75 SERIES

Kit: None, Bracket: 35-25, Nut: None

SERIES 380 and VANGUARD

Kit: K37-71, Bracket: 37-71, Nut: 37-345F




HPR100 and HPR180

Kit: A37-381, Bracket: 37-.364, Nut: None

MODULAR MOUNTING BRACKETS

Two L-shaped metal brackets as shown below can be used for wall mounting of modular **FRLs** or Clean Air Packages. A single bracket can be used to mount individual filters or lubricators. Kits include two brackets and four screws for attaching the brackets to the modules.




SENTRY

Screws: 10R-19 (2 required), Bracket: None


MINIATURE

Kit: K50-01, Bracket: 50-01 Note: minature can only be used in conjunction with 'T' suffix option on FD50, FCD50, and L50 products.



GUARDSMAN and Modular VANGUARD


Kit: K30-08, Bracket: 30-08



Kit: A118-103, Bracket: None

FRL INLINE MOUNTING PIPE BRACKETS

Two pipe brackets can be used for wall mounting of **FRL** assemblies that use pipe nipples to join the components. The bracket kits listed below include two sets of brackets.



Note: No mounting brackets available for PR180M, PRH180M, 1-1/4" or 1-1/2".